

WESSEX Low-Cost 600RES ELECTRIC THERMAL MODELS

Programme card suggested settings:

1. Brake - ON
2. Battery type - Ni-xx
3. Cut off type - soft-cut
4. Cut off voltage - Medium or Low
5. Start mode - Normal
6. Timing mode - High
7. Music - own choice
8. Governor mode - Off

Chris Hague

August 2014

Ref: ProgCard